

INSTRUCTIONS

hand sink cart

GENERAL USE

1. Plug in electric cord to a convenient 110 volt outlet.
2. Open “hot” side of valve on faucet about one quarter turn. Turn switch on electric box to start pump. With water heater turned “off”, allow pump to fill water heater until water begins to run out faucet spout, then shut valve.
3. Do the same for the “cold” side of faucet. This will “bleed” off air in water lines.
4. Turn “on” switch on side of water heater (switch will light up), and allow time for heater to begin heating water tank.
5. You are now ready to use the Hand Sink Cart.

CHANGING/EMPTYING WASTE TANKS

Turn hand sink off while changing tanks

1. To change to second tank supply, remove front fresh water tank.
2. Switch pump line from empty water tank to second full tank and place back into its position in front.
3. Briefly turn on faucet to check that pump is moving water through system. If so, close doors. You’re ready with 5 gallons more.
4. To empty full waste tanks, remove the drain nozzle from the full waste tank and place in the tank spout of the empty waste tank.
5. Empty waste at nearest safe disposal location.

VANCOUVER SHOWROOM INFO

#50 - 3711 North Fraser Way
Burnaby, B.C. V5J5J2
(P) 604-324-7368
(F) 604-324-6667
Toll Free: 1-877-379-7368

SEATTLE SHOWROOM INFO

4604 – 4th Avenue South
Seattle, WA 98134
(P) 206-749-5400
(F) 206-749-5432
Toll Free: 1-866-885-7368

The logo for Pedersen's, featuring the name in a stylized, cursive script font with a horizontal line underneath.

THE CELEBRATION EXPERTS

VANCOUVER, B.C. - SEATTLE, WA
www.pedersens.com

AFTER HOURS EMERGENCY INFO

Should an emergency arise after hours, please call your local Pedersen's office and your call will be directed to a staff member who can assist you.