

PARTS INCLUDED WITH EQUIPMENT

INSTRUCTIONS

propane oven (non-convection)

1. Turn on the propane at the source (propane tank) 5 minutes prior to lighting the oven
2. Locate pilot starter button (Red) on the front under the oven door
3. Hold the pilot button for 3 – 5 minutes (not to exceed 5 minutes). Please be extremely patient as this step is critical to the successful lighting of your oven
4. Continue to press red starter button. Hold flame to the pilot burner.
5. Once the pilot lights, continue to hold the button for another 30 – 60 seconds. The pilot light should remain lit. Set temperature gauge to desired position.
6. Release the red button. If the pilot light remains on, you may proceed to use the oven.

If the pilot light does not remain lit, repeat steps 4 - 6

Please handle with care and consideration.

Thank You.

VANCOUVER SHOWROOM INFO

#50 - 3711 North Fraser Way
Burnaby, B.C. V5J5J2
(P) 604-324-7368
(F) 604-324-6667
Toll Free: 1-877-379-7368

SEATTLE SHOWROOM INFO

4604 – 4th Avenue South
Seattle, WA 98134
(P) 206-749-5400
(F) 206-749-5432
Toll Free: 1-866-885-7368

The logo for Pedersen's, featuring the brand name in a stylized, cursive script font with a horizontal line underneath.

THE CELEBRATION EXPERTS
VANCOUVER, B.C. - SEATTLE, WA
www.pedersens.com

AFTER HOURS EMERGENCY INFO

Should an emergency arise after hours, please call your local Pedersen's office and your call will be directed to a staff member who can assist you.